



FIG. 3

FIG. 3 is a perspective view of a portable electronic device 1, shown in an open position. The device includes a main body 5 with a display 6 and a keypad 15. A hinge mechanism 9 is shown in a partially open position, revealing internal components such as a spring 900, a latch 902, and a release button 906. The device is shown in a perspective view, with various components labeled with reference numerals.




FIG. 12

